



**SERVICE MENU:**  
 TURN OFF POWER (S1)  
 HOLD S6 AND S7 THEN TURN POWER ON (S1)  
 HOLD S6 AND S7 FOR ANOTHER 5 SEC WHEN POWER IS ON

ROTATE DIAL J1 TO SCROLL THROUGH SERVICE MENU  
 PRESS S3 TO ACCESS MENU STEP  
 FOR LEAVING EACH STEP TO BACK MENU, PRESS S7  
 PRESSING S3 STORES ALL SELECTIONS MADE AND EXITS SERVICE MENU

