


WARING COMMERCIAL®


Europe Heavy-Duty Double Waffle Maker WW200E



032364
Cup



032350
Drip Pan



032765
Complete Unit Assembly

Illustration#	Part#	Description
1	037968	Handle (top and bottom)
2	037970	Screw (2 required on both the top & bottom waffle plate)
3	032359	Screw (2 required on both the top & bottom handle half)
4	032359	Screw (2 required on both the top & bottom handle half)
4A	037969	Washer (2 required on only the top handle half)
5	037537	Screw (2 required on both the top & bottom waffle plate)
6	032745	Browning Control Knob with Insert
7	012703	Switch Boot
8	032356	Washer
9	032747	ON-OFF Toggle Switch
10	032358	Darkness Control Panel w/Long Lead Tape (thermostat)
11	034162	Connector Pole
12	032359	Thermostat Screw (3 required)
13	032359	Power Board Screw (4 required)
14	032763	PCB Board and Power Board Assembly
15	032359	PCB Board Screw (4 required)
16	032367	Red Lead
17	032764	Green-Yellow Lead
18	013731	Wire Tie (7 required)
19	019123	Large Crimp Connector (2 required)
	012409	Small Crimp Connector (4 required)
20	032751	Ground Spring Washer
21	035298	Ground Screw
22	032361	Strain Relief
23	032748	Cord Set
24	032371	Cord Plate
25	032351	Bottom Plate
26	032353	Foot (4 required)
27	032354	Foot Washer (4 required)
28	032355	Foot Screw (4 required)
29	032751	Bottom Plate Spring Washer (4 required)
30	032750	Bottom Plate Screw (4 required)